



FORD MUSTANG **Trunk Lid Installation Guide** **(1999 to 2004 models).**

READ ALL THE DIRECTIONS BEFORE INSTALLING MAT.

Tools needed

- drill with ¼" bit.
- Scratch Awl or Center Punch
- Knife
- Electrical Tape
- Pencil or China Marker



☹☹☹ LEARN FROM OTHERS MISTAKES

Do not attempt to drill the holes in the hood through the mat holes. Drill bit could snag the fabric and start winding it around the bit, and tear the fabric.

Step 1

Hold your new Trunk-lid mat against the upper trunk lid and adjust to desired fit. (It may be easier to have someone assist you.) **MASKING TAPE (ANY OTHER KIND OF TAPE COULD DAMAGE THE PAINT FINISH)** can be used to hold the mat while adjusting the fit. Next, once the trunk lid mat is adjusted, take the punch Awl and place it in the holes on the trunk-lid mat and gently dimple the area by striking the Awl with the hammer, a pencil can be used to mark the spots then dimple the area to be drilled.



Step 2

Check the area to make sure that the holes are not too close to the edge of the expanded metal or fiberglass. If they are too close to the edge of the raised frame, please check fit again. Next, drill the hole locations with the ¼ drill-bit (Fig 3). Take your time and do not put too much pressure on the drill. If you do, when it “pops” through, you risk creating a BB size dent on the top (exterior) of your trunk-lid. You may even tape the bit about ¼ inch from the end of the bit. This will also slow the bit and help prevent it from hitting the bottom bit side of the deck-lid.



FIG 3

Step 3

Once the ¼ holes have been drilled, hold the mat up to the trunk-lid and align the holes.

If they do not line up, check to see that the holes were drilled correctly. Take each of the supplied retaining clips and push through the holes on the mat and into the drilled holes. When they are sideways or not fitted properly, they make break. These clips are a one-time use and maybe damaged easily when removed without the proper removal tool. **Never attempt to remove the mat by pulling on it. This can damage the mat or rip the holes from the mat. Also never hammer the clips in.**

The manufacturer of the MDM Mat would like to thank you again for your purchase.

Limited Warranty:

These handcrafted deck lid Mats are warranted for 120-days against defects in workmanship or materials. If you have a problem with your new deck lid mat within this time, please contact granddesignmat@aol.com for assistance.

*The MDM Trunk Mat is made by Grand Design Mat
Copyright 2000 to 2010 . Brown Summit NC U.S.A.*

Note: This deck lid may contain materials that are not flame resistant. Please keep away from open flames or electrical sources in your vehicle. The manufacturer and websites that sell this item are not responsible for any injury or damage that may result from improper use or improper installation of this product to car nor person(s).